

Container Handler

Used Container Handler West Covina - Container handlers are also called container ships and cargo ships since they transport loads in sizeable intermodal containers. Containerization is the shipping method that utilizes commercial freight transport to carry seagoing cargo in non-bulk sizes. Container ship capacity is measured in units that are equal to 20' equivalent loads. The majority of typical loads consist of a mix of 40-foot containers and 20-foot containers. Approximately ninety percent of non-bulk cargo across the globe is transported by container ships. Container handlers are one of the biggest vessels sailing and are the main rival for oil tankers on the ocean. Dry cargo is categorized into two main types: break-bulk cargo and bulk cargo. Coal and grain are considered to be bulk cargo items. They are typically transported in their raw form within the hull of the ship, free from packages in immense volume. Break-bulk cargo items normally consist of manufactured goods that are transported in packages. Before containerization was invented in the 50s, break-bulk items were loaded, secured and unlashd one item at a time. When the cargo was grouped into containers, there were approximately 1000-3000 cubic feet of cargo that can be simultaneously moved after each unit has been standardized and secured. Efficiency has tremendously increased break-bulk cargo shipping. Costs have been reduced to around 35% and shipping time has been reduced by 84%! In 2001, over ninety percent of non-bulk materials were recorded as being transported in containers. The initial container ships in the 1940s were designed from tankers that were converted post-WWII. Cargo ships do not use individual dividers, holds or hatches that are a part of traditional container ships. Essentially the container ship's hull is similar to a huge warehouse that uses vertical guide rails to divide it into cells. These cells have been engineered to hold the cargo in containers. Most shipping containers are constructed from steel; however, additional materials including plywood, fiberglass and wood are used. Designed to be completely transferred to and from trains, semi-trailers, trucks, coastal carriers and more, there is a variety of container types that are categorized by their function and size. The entire shipping industry has been revolutionized by containerization, although, it did not start out in the easiest manner. At first, many companies and shippers were worried about the huge costs associated with constructing ports, railway infrastructure and the roads needed to transport items via cargo ships. There was skepticism regarding potential dock and port worker job loss when containerization was announced for fear that numerous manual jobs would disappear.

Approximately ten years of legal battles occurred prior to container ships began international service. A container liner service from the Dutch city of Rotterdam to the USA first started in 1966, soon to change world trade and shipping across the globe. Loading and unloading of cargo ships has been reduced to a few hours instead of the days it used to take traditional cargo vessels. Shipping times have been shortened in between ports extensively along with labor finances. It only takes 3 weeks to have materials delivered from Europe to India as opposed to the months it used to require. Generally, there is less damage to materials thanks to less frequent handling. Securing loads properly also helps with less cargo shifting during transport. Before shipping, containers are closed and only opened after they arrive at their new location to prevent theft and damage. There has been greater international trade growth due to the reduced shipping expenses and travel time delivered by container ships. Cargo that used to arrive in bales, crates, bags, cartons or barrels now arrives in containers sealed from the factory. Scanning machines work with computers to trace the product code on the contents. Technology has made this tracking system accurate and exact to enable a two week voyage to be timed for arrival within an accuracy rate of under fifteen minutes. This has helped with guaranteed delivery and manufacturing times. Raw materials show up in sealed containers from factories in under an hour prior to being used in the manufacturing industry; resulting in fewer inventory expenses and greater accuracy. Boxes are provided by shipping companies to the exporters to facilitate loading merchandise. They are delivered into the docks by rail or road or a combination of both to be loaded onto container ships. Containerization has streamlined the process of loading by reducing the number of workers

and hours it takes to fit cargo into their holds. The shipping industry today relies on cranes either installed on the ship or on the pier to situate containers on board. More containers can be loaded onto the deck after the hull is loaded. Efficiency has been one of the main design elements for cargo ships. Containers may travel on break-bulk vessels. However, cargo holds that have been dedicated to container ships have been carefully built to speed up the loading and unloading process and designed to keep containers secure while traveling the ocean. A specially designed hatch creates openings to access the main cargo holds from the deck. A raised steel apparatus called the hatch coaming surrounds these openings that are found along the cargo hold breadth. There are secure hatch covers situated on top of the hatch coamings. Wooden boards and tarps initially covered the hatches and held the battens secure until the 50s. Nowadays, solid metal plates comprise the hatch covers and cranes lift them onboard and off of the ship. There are other hatch models that rely on articulated mechanisms that use strong hydraulic rams for opening and closing. Cell guides are another main component within container ship design. Attached to the cargo hold in the ship, cell guides are vertical pieces of metal that help organize the cargo. These guide containers into specific rows during the loading process and offer support during sea travel. The design of the container ship uses cell guides enough that the United Nations Conference on Trade and Development utilize them to distinguish between container ships and regular break-bulk cargo ships. To showcase a container's position on the ship, there is a cargo plan system that use three dimensions. The first coordinate is the bay which begins at the front of the ship and increases aft. The second coordinate is the tier. The first tier begins in the lower portion of the cargo holds with the second tier found on top of the first tier and continuing in that fashion. The row is the third coordinate. Rows are situated on the ship's port side have even numbers while those found starboard have odd numbers. Rows found along the centerline are given lower numbers and these numbers increase for slots situated further from the center. Container handlers carry 20, 40 and 45 foot containers. The largest size fits only above deck while the 40 foot size makes up for the majority of the load or approximately ninety percent of the container shipping. Container shipping is responsible for moving approximately ninety percent of the freight across the globe, while roughly eighty percent of global freight moves with 40 foot containers.